

///MotionScope® M3

Redlake's *MotionScope*® M3 high-speed CMOS camera combines ease-of-use and value for your high-speed motion application. The *MotionScope* M3 offers maximum resolution of 1280 x 1024 at 500 fps with frame rates up to 32,000 fps at reduced resolutions.

Specifically optimized for industrial applications, the innovative Redlake *MotionScope* M3 high-speed digital camera architecture puts it in a class by itself. Small, lightweight, stand-alone battery operation, and Firewire network connectivity are just a few attributes of the *MotionScope* M3 camera.

The *MotionScope* M3 features built-in image memory for storing the recorded high-speed sequence for playback, editing or downloading to the PC's hard disk. Just choose which image memory option best fits your application requirements. Flexible triggering lets you create the best pre- and post- event trigger settings enabling you to capture perfect images every time.

The *MotionScope* M3's internal battery comes standard and provides up to 30 minutes of standalone operation and up to 4 hours in stand-by mode. Since the *MotionScope* M3 is self-contained (no bulky processor or tethered cables to contend with) the only connection required is a trigger signal.

Thanks to its intuitive and reliable "point and click" Windows control software, the *MotionScope* M3 is exceptionally simple to set up and operate. Advanced features are included in the standard Image Studio software. The camera is interfaced to your PC via a standard Firewire (IEEE-1394) interface.

Small and Lightweight High-Speed Industrial Camera



S N A P S H O T

- **Compact: 125 x 67 x 67 mm and only 1.65 lb (0.75 kg)**
- **Sturdy metal housing to withstand harsh industrial environments**
- **Speeds of 500 fps at a full resolution of 1280 x 1024 up to 32,000 fps with reduced resolutions**
- **Internal battery to provide power for up to 30 minutes in recording mode (and up to 4 hours in standby mode)**
- **Firewire interface for easy set-up and fast image downloading**

A P P L I C A T I O N S

- **Process control**
- **Process engineering**
- **Quality inspection / control**
- **Research (materials, biotechnology, etc)**

MotionScope® M3

PERFORMANCE SPECIFICATIONS

Resolution	1280 x 1024 pixels full frame (8-bit mono or 24-bit color)
Speed	62 to 32,000 fps
Exposure rates	Global electronic shutter, speeds from 4 µsec to 1 / frame rate
File formats	Raw data (Bayer), AVI, BMP, GIF, JPEG, MPEG, TIFF
Frame storage	1024 frames at 1280 x 1024 (2 seconds record time at 500fps)
Memory upgrade	2048 frames at 1280 x 1024 (4 seconds record time at 500fps)
Power	Power via FireWire or 12 vdc power supply
Software	Image Studio for Windows XP or 2000
Standard Lenses	C-mount (1" format); includes F-mount adapter; other adapters optional
Camera Size	4.92" x 2.64" x 2.64" (125 x 67 x 67 mm)
Weight	1.65 lb (0.75 kg) including standard battery
Battery capacity	Recording mode capacity: 30 min.; stand-by mode capacity: 4 hours

Note: Specs are subject to change at any time

MotionScope M3 1.3 GB Memory - Sample Frame Rates

Resolution	Frame Rate	Number of Frames	Duration
1280 x 1024	500 fps	1024	2 seconds
640 x 512	1000 fps	4096	4 seconds
320 x 256	2000 fps	16,384	8 seconds
320 x 128	4000 fps	32,768	8 seconds
160 x 64	8000 fps	65,536	16 seconds
160 x 32	16,000 fps	262,144	16 seconds
160 x 16	32,000 fps	524,288	16 seconds

MotionScope M3 2.6 GB Memory - Sample Frame Rates

Resolution	Frame Rate	Number of Frames	Duration
1280 x 1024	500 fps	2048	4 seconds
640 x 512	1000 fps	8192	8 seconds
320 x 256	2000 fps	32,768	16 seconds
320 x 128	4000 fps	65,536	16 seconds
160 x 64	8000 fps	262,144	32 seconds
160 x 32	16,000 fps	524,288	32 seconds
160 x 16	32,000 fps	1,048,576	32 seconds

Worldwide Sales and Support

Americas
tel: +1-800-462-4307
tel: +1-858-481-8182
sales@redlake.com

Asia Pacific
tel: +65-6293-4758
salesASPAC@redlake.com

Japan
tel: +81-3-5639-2770
salesJapan@redlake.com

Europe, Africa and Middle East
tel: +31-347-324989
salesEurope@redlake.com

Copyright © 2004 Redlake, MASD, LLC

All Rights Reserved

MotionScope M3 Rev. A

